


# DB37-TS-6 Cable



**TS-140 TS-440 TS-450 TS-680 TS-690 TS-711 TS-790 TS-811 TS-850 TS-940 TS-950**

**Notes:**

- \* FSK RCA is necessary only for the TS-850 TS-950
- \*\* PTT2 mutes front MIC

**S = Sleeve**  
**T = Tip**  
**R = Ring**

TS140 , TS680 - requires Kenwood IF-10C  
 TS711 , TS811 - requires Kenwood IF-10A  
 TS 940 - requires Kenwood IF-10B  
 TS 440 - requires Kenwood IC-10