


DigiKeyer and ACLog setup

Router setup:

Note: The absolute port numbers do not matter. The key is consistency - the same port number must be used for a specific function every time it is used.


1. Assign the radio control virtual COM port.
2. Assign a port for CW.
3. Assign a port for PTT if you intend to use the ACLog DVK with another sound card.
4. Assign a port for FSK if you intend to use MMTTY for RTTY.




5. Save the settings to a preset by selecting **Preset | Save as**. Choose a position and name it ACLog.

ACLog setup:

1. Click **Settings | Rig Interface** to configure the radio interface.



2. Select your Rig
3. Select the Port you assigned for Control in Router
4. Set the Baud Rate, Data Bits, Parity and Stop Bits settings required by your radio.
5. Click Done to save your settings



6. Click **Settings | Transmit | CW Setup**
7. Select DTR and the Port you assigned for CW in Router.
8. Click Done to save your settings

9. If you intend to use the ACLog DVK, click **Settings | Transmit | Phone Setup**
10. Select RTS and the Port you assigned to PTT in Router.
11. Click Done to save your settings.

