


USB Interface II and XMlog Setup

Router setup:


Note: The absolute port numbers do not matter. The key is consistency - the same port number must be used for a specific function every time it is used.

1. Assign the radio control virtual COM port.
2. Assign a port for CW and PTT.



3. Save the settings to a preset by selecting **Preset | Save as**. Choose a position and name it XMlog.

XMlog setup:



1. Click **Options | HF Rig Port Select ->**
2. Set your radio
3. Select the virtual COM port you used for Control in Router's Ports tab
4. Set BAUD, Data Bits, Stop Bits and Parity required by your radio.
5. Set Flow Control to None.

6. Click **Options | CW Options and Port Select ->**
7. Select **PC Generates ...**
8. Set the port you set for WinKey on the Ports tab.
9. Select Enable PTT and/or Enable sidetone as you prefer.

